




































Original	Replacement
Power	Power
Sleep	Sleep
CBL/SAT	1
DVD	2
Blu-ray	3
Game	4
AUX	5
Media Player	6
Tv Audio	7
BK	8
Tuner	9
USB	Guide
Play	Play
CD	0
Bluetooth	Pre Ch
Phono	Dual
Phono	Smart

Original	Replacement
Internet Radio	Media
Eco	3D
CH/Page+	Ch +
CH/Page-	Ch -
Vol+	Vol +
Vol-	Vol -
Mute	Mute
Info	Info
Option	Options
Back	Back
Setup	Menu
Up	Up
Down	Down
Right	Right
Left	Left
Enter	Ok
>>I/Tune+	>>I





Original	Replacement
 Power	 Power
 Sleep	 Sleep
 CBL/SAT	 1
 DVD	 2
 Blu-ray	 3
 Game	 4
 AUX	 5
 Media Player	 6
 Tv Audio	 7
 BK	 8
 Tuner	 9
 USB	 Guide
 CD	 0
 Bluetooth	 Pre Ch
 Phono	 Dual
 Internet Radio	 Smart
	 Media

Original	Replacement
 CH/Page+	 Ch +
 CH/Page-	 Ch -
 Vol+	 Vol +
 Vol-	 Vol -
 Mute	 Mute
 Back	 Back
 Up	 Up
 Down	 Down
 Right	 Right
 Left	 Left
 Enter	 Ok
 Play	 Play
 >>I/Tune+	 >>I
 I<</Tune-	 I<<
 Pause	 Pause
 Quick Select 1	 D. Menu
 Quick Select 2	 Text



