







































































| Original | Replacement | Original | Replacement |
|---|--|---|---|
|  Power |  Power |  Play |  Play |
|  1 |  1 |  I<</Tune- |  I<< |
|  2 |  2 |  >>I/Tune+ |  >>I |
|  3 |  3 |  << |  << |
|  4 |  4 |  Pause |  Pause |
|  5 |  5 |  Stop |  Stop |
|  6 |  6 |  >> |  >> |
|  7 |  7 |  Info |  Info |
|  8 |  8 |  Option |  Options |
|  9 |  9 |  Setup |  Menu |
|  0 |  0 |  Back |  Back |
|  Enter2 |  Pre Ch |  Up |  Up |
|  Green/Movie |  Green |  Down |  Down |
|  Red/Music |  Red |  Right |  Right |
|  Blue/Game |  Blue |  Left |  Left |
|  Yellow/Pure |  Yellow |  Enter |  Ok |
|  Sleep |  Sleep |  Vol+ |  Vol + |









































































| Original | Replacement |
|--------------------|-------------|
| Vol- | Vol - |
| Mute | Mute |
| CH/Page+ | Ch + |
| CH/Page- | Ch - |
| InstaPreviee | Smart |
| Favorite Station 1 | D. Menu |
| Favorite Station 2 | Text |
| Favorite Station 3 | Eject |
| Favorite Station 4 | AV |
| CBL/SAT | Shift + 1 |
| DVD | Shift + 2 |
| Tv Audio | TV/R |
| Bluray | Shift + 3 |
| AUX1 | Shift + 4 |
| Tuner | Shift + 5 |
| Game | Shift + 6 |
| AUX2 | Shift + 7 |

| Original | Replacement |
|----------------|----------------|
| Phono | Shift + 8 |
| iPod/USB | Shift + 9 |
| Media Player | Shift + Guide |
| CD | Guide |
| Network | Shift + 0 |
| Internet Radio | Shift + Pre Ch |








































































| Original | Replacement | Original | Replacement |
|---|--------------------|---|-------------|
|  | Power |  | Power |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | Enter2 |  | Pre Ch |
|  | Play |  | Play |
|  | I<</Tune- |  | I<< |
|  | >>I/Tune+ |  | >>I |
|  | << |  | << |
|  | Pause |  | Pause |
|  | Stop |  | Stop |
|  | >> |  | >> |
|  | Back |  | Back |
|  | Up |  | Up |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Left |  | Left |
|  | Enter |  | Ok |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | Mute |  | Mute |
|  | CH/Page+ |  | Ch + |
|  | CH/Page- |  | Ch - |
|  | Favorite Station 1 |  | D. Menu |
|  | Favorite Station 2 |  | Text |
|  | Favorite Station 3 |  | Eject |
|  | Favorite Station 4 |  | AV |





| Original | Replacement | Original | Replacement |
|---|--------------------|---|-------------|
|  | Power |  | Power |
|  | 1 |  | 1 |
|  | 2 |  | 2 |
|  | 3 |  | 3 |
|  | 4 |  | 4 |
|  | 5 |  | 5 |
|  | 6 |  | 6 |
|  | 7 |  | 7 |
|  | 8 |  | 8 |
|  | 9 |  | 9 |
|  | 0 |  | 0 |
|  | Enter2 |  | Pre Ch |
|  | Sleep |  | Sleep |
|  | Play |  | Play |
|  | I<</Tune- |  | I<< |
|  | >>I/Tune+ |  | >>I |
|  | << |  | << |
|  | Pause |  | Pause |
|  | Stop |  | Stop |
|  | >> |  | >> |
|  | Back |  | Back |
|  | Up |  | Up |
|  | Enter |  | Ok |
|  | Down |  | Down |
|  | Right |  | Right |
|  | Left |  | Left |
|  | Vol+ |  | Vol + |
|  | Vol- |  | Vol - |
|  | CH/Page+ |  | Ch + |
|  | CH/Page- |  | Ch - |
|  | Mute |  | Mute |
|  | Favorite Station 1 |  | D. Menu |
|  | Favorite Station 2 |  | Text |
|  | Favorite Station 3 |  | Eject |



