






Original	Replacement
	Power
	CBL/SAT
	DVD
	Tv Audio
	Blu-ray
	AUX
	Tuner
	Bluetooth
	Game
	8K
	Phono
	USB
	Media Player
	CD
	..I..
	Internet Radio
	Quick Select 1
	Power
	AV / Input / RDS
	Shift + 2
	Audio / Lang I/II
	Shift + Blue / Prime
	Shift + 7
	Shift + 6
	Shift + 9
	Shift + Green / APP /
	Shift + Yellow / YouTube /
	Guide / EPG / -/--
	Shift + 8
	Display / Media
	Shift + 3
	Shift + 0
	TV/Radio /
	Sound / Title

Original	Replacement
	Quick Select 2
	Quick Select 3
	Quick Select 4
	CH+ / Page+
	CH- / Page-
	Eco
	Mute
	Volume+
	Volume-
	Info
	Option
	Back
	Setup
	Up
	Down
	Left
	Right
	Picture / Format
	D.Menu / Top
	Zoom / Size
	CH+ / Page+
	CH- / Page-
	Smart / List
	Mute / Dimmer
	Vol+
	Vol-
	Info / Angle
	Shift + Setup / OPT / Tools
	Back / Return
	Setup / OPT /
	Up
	Down
	Left
	Right








Original	Replacement
 Power	 Power
 CBL/SAT	 AV / Input / RDS
 DVD	 Shift + 2
 Tv Audio	 Audio / Lang I/II
 Blu-ray	 Shift + Blue / Prime
 AUX	 Shift + 7
 Tuner	 Shift + 6
 Bluetooth	 Shift + 9
 Game	 Blue / Prime Video / Random
 8K	 Yellow / YouTube / Repeat
 Phono	 Guide / EPG / -/--
 USB	 Shift + 8
 Media Player	 Display / Media
 CD	 Shift + 3
 .:I.:	 Shift + 0
 Internet Radio	 TV/Radio /
 Quick Select 1	 Sound / Title

Original	Replacement
 Quick Select 2	 Picture / Format
 Quick Select 3	 D.Menu / Top
 Quick Select 4	 Zoom / Size
 CH/Page Up	 CH+ / Page+
 CH/Page Down	 CH- / Page-
 Mute	 Mute / Dimmer
 Volume+	 Vol+
 Volume-	 Vol-
 Up	 Up
 Down	 Down
 Left	 Left
 Right	 Right
 Back	 Back / Return
 I<</Tune-	 I<< / Preset-
 Play	 Play / Slow
 >>I/Tune+	 >>I / Preset+
 <<	 << / Tune-







Original	Replacement
	Power
	CBL/SAT
	DVD
	Tv Audio
	Blu-ray
	AUX
	Tuner
	Bluetooth
	Game
	8K
	Phono
	USB
	Media Player
	CD
	Internet Radio
	Quick Select 1

Original	Replacement
	Quick Select 2
	Quick Select 3
	Quick Select 4
	CH/Page Up
	CH/Page Down
	Mute
	Volume+
	Volume-
	Up
	Down
	Left
	Right
	Back
	I<</Tune-
	Play
	>>I/Tune+
	<< / Tune-





Original		Replacement		Original		Replacement	
	Pause		Pause / Step / Freeze				
	Stop		Stop / Hold				
	>>		>> / Tune+				
	1		1				
	2		2				
	3		3				
	4		4				
	5		5				
	6		6				
	7		7				
	8		8				
	9		9				
	0		0				
	Enter		OK				
	Sleep		Sleep / Timer				

